

# Portable Scoreboard T-Cart Leg Kit Assembly Instructions

## What's included:

- One leg assembly with wheels
- One leg assembly without wheels
- Four 2-inch 1/2-13 UNC bolts

## What you will need:

- Two people (for lifting)
- A 3/4-inch wrench
- An Electro-Mech portable scoreboard

**ELECTROMECH**  
SCOREBOARD COMPANY

72 Industrial Boulevard  
Wrightsville, GA 31096  
Phone: (800) 445-7843  
Fax: (800) 864-0212  
www.electro-mech.com

April 3, 2012

Revision 1

*If you ordered this kit along with your scoreboard, the bolts will arrive threaded into the mounting point on each side of the scoreboard.*



The leg assemblies attach to each side of the scoreboard cabinet using the provided bolts. Either leg can be attached to either side.



Attach the leg assembly **WITHOUT** wheels first. One person should support the cabinet while the other threads the bolts.



Use 3/4-inch wrench to tighten the bolts. A torque of 30 ft. lbs. is sufficient to keep the legs in place under typical conditions.



One person should lift the scoreboard cabinet into position using the attached leg assembly as a pivot while the other attaches the second leg.



Attach the leg assembly **WITH** wheels. The wheels may be oriented toward the inside or outside of the scoreboard cabinet.



After a final check on all four bolts, use the leg assembly **WITHOUT** wheels as a handle to guide your scoreboard to its final position.