




Summary

The Electro-Mech Wireless Handheld Pitch Count Switch Assembly is an accessory which works with MP-style control console outfitted with an embedded ScoreLink Transmitter and the appropriate software. This handheld unit allows an umpire or other designee to update the pitch count on the scoreboard display from outside the press box.

Buttons and Indicators

Home Pitching Indicator Light = Illuminates when the Guest team is at bat and the Home team is pitching.



Pitches +1 = Increase the pitch count.

Pitches -1 = Decrease the pitch count.

Team Pitching = Toggle between Home and Guest pitch count.

Mode = Toggle between checking the battery strength or signal strength. Press and hold this button to put the handheld unit in low power mode. Press again to resume normal operation.

Battery Strength Indicator Light = Illuminates solid amber while the green Strength Bar Indicators display the handheld unit's battery strength. This LED will blink on once every five seconds when the batteries need to be replaced. It will illuminate briefly when the device powers up fully.

Signal Strength Indicator Light = Illuminates solid amber while the green Strength Bar Indicators display the handheld unit's signal strength. This LED will blink once every two seconds when the handheld unit is unable to find a ScoreLink server. It will illuminate briefly when the device powers up fully.

Strength Bar Indicator Lights = Illuminate solid green as strength increases; more lights mean more strength.

Batteries

The Handheld Pitch Count Switch Assembly requires two AA batteries to power it for wireless operation. These can be standard alkaline batteries or rechargeable batteries. Either style should provide over 20 hours of operation on a fresh charge. You cannot recharge batteries inside the handheld unit.

Electro-Mech's wireless switch assemblies are designed to conserve battery power when they are not active. The units drop into a lower power mode when they are unable to detect the presence of a ScoreLink server for several minutes. You can manually activate this low power feature by holding the [MODE] button for about five seconds. However, the internal electronics continue to drain the batteries slightly. We recommend removing the batteries from units that will not be in use for a few days.

